

NOTES

- (1) A 60 lb Quikrete bag yields 0.3 ft³. A minimum of 2" thick pad is required for proper sealing.
- (2) A total of 60 minutes of working time is required.
- (3) Add the correct amount of water depending on the bag size of Quikrete.
- (4) Provisions must be made to protect conduit protrusions with concentric neutrals from the natural corrosive properties of the cement by using a duct collar or by taping the area.