



NOTES

- (1) Transformer pad may be integral with meter enclosure pad.
- (2) Enclosure must be positioned on secondary side of transformer.
- (3) Thirteen-terminal socket should be sent to PNM for pre-wiring.

REFERENCES

- (1) See DS-7-16.0 For Transformer Pad
- (2) See MS-2-7.0 Three-Phase Thirteen-Terminal Socket for CT Meter
- (3) See MS-3-11.0 120/208-277/480V CT Meter Enclosure
- (4) See MS-3-14.0 120/208-277/480V Transformer and Meter Enclosure
- (5) See MS-3-16.0 120/208-277/480V Enclosure Pad
- (6) See MS-7-2.0 Working Space Required for Meter Enclosure

Maintenance Only

Important:

Socket shall be wired phase 1-2-3 from left to right and the conductors marked as such. Each conductor phase will be identified at the weather head or padmount, and at the meter base using band-wraps of electrical tape:

- One band for phase one
- Two bands for phase two
- Three bands for phase three
- White tape is suitable for neutral conductors only.