



NOTES

- (1) Bucket access is required for construction and maintenance.
- (2) Design not suitable for raptor protection.
- (3) Alley arm to always be used with a brace.

REFERENCES

- (1) See DS-6-1.0 Alley Arm with Brace
- (2) See DS-18-25.0 Length of Bolts
- (3) See Section 18 for Individual Details
- (4) See DM-17-1.0 Pole Loading

Material List			
Item	Quan.	Description	Stock #
A	3	___ kV Pin Insulator	
B	1	Alley Arm with Brace	0100-005843
C	1	One Wire Rack	DS-18-18.0
D	3	___ Line Tie	5975-
E	1	___ Spool Line Tie	5975-
F	1	___ Wood Pole	DM-17-1.0
G		Single Distribution Bracket	

Three-Phase Alley Arm with Brace

DS-2-16.5