



**Important:**

Socket shall be wired phase 1-2-3 from left to right and the conductors marked as such. Each conductor phase will be identified at the weather head or padmount, and at the meter base using band-wraps of electrical tape:

- One band for phase one
- Two bands for phase two
- Three bands for phase three
- White tape is suitable for neutral conductors only.

**NOTES**

- (1) Thirteen-terminal meter socket may be mounted on either side of CT enclosure when the proper clearances are met.
- (2) Customer will furnish both meter socket and CT enclosure.
- (3) Thirteen-terminal meter socket should be sent to PNM for pre-wiring.
- (4) PNM will mount thirteen-terminal meter socket, transformer, meter and meter wiring.
- (5) Enclosure must comply with PNM specification M-1.

**REFERENCES**

- (1) See MS-2-7.0 Three-Phase Thirteen-Terminal Socket for CT Meter
- (2) See MS-3-16.0 120/208-277/480V Enclosure Pad
- (3) See MS-7-2.0 Working Space Required for Meter Enclosure

Maintenance Only

Approved Equipment		
Manufacturer	Item	Mfg Part #
Shallbetter	Enclosure	SPML-3480-514242-GA-PNM
Sunwest	Enclosure	SW-1976

120/208-277/480V CT Meter Enclosure

MS-3-11.0