



**NOTES**

- (1) Rain tight housing should be used if switchgear is mounted in unprotected location.
- (2) Switchgear and transformer may be mounted on common pad.
- (3) Guard posts will be required in traffic areas.
- (4) Customer building number must be permanently painted under main disconnect.

**REFERENCES**

- (1) See Section 7 for individual pad details
- (2) See DS-7-16.10 Guard Post
- (3) See MS-4-5.0 Raintight Housing for Switchgear and Meter
- (4) See MS-4-8.0 Switchgear Seven-jaw Socket Meter
- (5) See MS-4-9.0 Cradle Mount CT Switchgear Metering
- (6) See MS-4-10.0 Base Mount CT Switchgear Metering

**Important:**

Socket shall be wired phase 1-2-3 from left to right and the conductors marked as such. Each conductor phase will be identified at the weather head or padmount, and at the meter base using band-wraps of electrical tape:

- One band for phase one
- Two bands for phase two
- Three bands for phase three
- White tape is suitable for neutral conductors only